

## 高黏度攪拌機 High Viscosity Type Stirrer

53

攪拌機系列  
Stirrer Series



SP-100

### 特點：

- 本機為容器旋轉式攪拌機，適用於高黏度流動性不佳之液體，攪拌棒採全不鏽鋼製造，另配備轉速指示錶及定時裝置。適用於一般油墨塗料之攪拌與混合，如金粉、銀粉、夜光粉等，亦可作感光乳劑之攪拌。
- SP-200S為真空型容器旋轉式攪拌機，採真空攪拌方式，可在運轉中減少氣泡產生，並自動消泡混煉，一次完成，附真空指示計及調節洩壓閥。



SP-200S

### Feature :

- This machine is a container rotary stirrer, suitable for mixing poor fluid and high viscous liquid, which is with a stainless stirring shaft and also equipped with a RPM tachometer and timer, and suitable for mixing normal ink and paint, such as gold powder, silver powder, luminous powder, etc., also can stir the emulsion.
- SP-200S is a container rotary & vacuum-type stirrer; accomplishes the stirring effect by rotating the entirely vacuum container, and air bubble happening can be reduced during the operation, finally automatically anti-foaming and mixing efficiency help to complete the job at one time. A vacuum gauge and a decompressing valve are attached.

Model	SP-100	SP-200S
容量 Capacity (L)	0.2~5	
計時器 Timer (min.)	10~60 or "ON"	
轉速 Speed (rpm)	0~100 (50Hz) / 0~120 (60Hz)	
重量 Weight (kg)	16	42
尺寸 Size (W x L x H mm)	330 x 236 x 593	460 x 292 x 670
電源 Power	AC 110V/220V, 50/60Hz	