Thermo Scientific AquaSensors DataStick

pH measurement system

Thermo Scientific[™] AquaSensors DataStick measurement system for universal plug & play.

Markets/Applications

- · Wastewater treatment
- · Neutralization of effluent
 - Steel
 - Pulp and paper
 - Food
 - Chemical
 - Pharmaceutical
- Metal finishing (chrome/cyanide destruct)
- High purity water
- Odor scrubbers
- Pharmaceutical
- Chemical & petrochemical
- Reverse osmosis
- · Cooling tower control
- Food processing
 - Carbon dioxide control
 - Cleaning
 - Canning



Thermo Scientific™ AquaSensors pH DataStick™

- Differential pH measurement
- Pre-calibrated (no field calibration required)
- · Plug & play sensor heads
- Replaceable quad junction salt bridges
- · Electrode protection options
- Offered in a variety of materials
- Direct data reporting (24-bit)
- Plug & play industrial communications adapters

Connect this pH sensor directly to a PLC (Programmable Logic Controller) for seamless integration with industrial control systems. Use any computer to display data, calibrate and customize the measurement without an intermediate analyzer electronics box. Sensor heads are pre-calibrated and can be replaced or exchanged with any other type of sensor without taking the system down. Save space, time and money.



Engineering Specifications

- The pH sensor shall be of Differential Electrode Technique design using two electrodes to compare the process value to a stable internal reference standard buffer solution. The standard electrode shall have non-flowing and fouling-resistant characteristics.
- 2. The sensor shall have hex-shaped wrench flats to facilitate mounting, and shall be constructed of a material with exceptional chemical resistance and mechanical strength. This material shall enable the sensor to be installed in metal fittings without leakage usually caused by heating and cooling cycles when dissimilar materials are threaded together.
- The sensor shall have interchangeable, pre-calibrated plug-in sensor heads and communications adapters that can be installed without powering down the system.
- The sensor shall have 1 inch NPT threads on both ends to mount into a standard 1 inch pipe tee, a 1.5 inch union mounting, or immersion hardware.
- The built-in electronics of the sensor shall be completely encapsulated and O-ring sealed for protection from moisture and humidity.
- The sensor shall have a built-in pre-amplifier, universal signal conditioning electronics, universal engineering

units conversion, and interactive communications with a host computer or display interface using one of several protocols including Modbus[®] RTU, DeviceNet[™], PROFIBUS[™], USB, CANopen or Ethernet.

- The sensor shall have an integral temperature sensor to automatically compensate measured values for changes in process temperature.
- 8. The sensor shall include a titanium ground electrode (standard) to eliminate ground loop currents in the measuring electrode.
- 9. The sensor shall be Thermo Scientific AquaSensors pH DataStick.



Thermo Scientific DataStick Analytical System

Key Components

DataStick

Provides universal conversion of sensor signals and interactive communications for measurement, calibration, configuration and diagnostics.

Communications Adapter

Plugs into the DataStick to provide power and direct interactive communications with control systems.





Differential pH Sensor Head

Pre-calibrated for pH and temperature. Can be plugged into any DataStick to yield accurate 24-bit data.







Thermo Scientific AquaSensors pH DataStick

Provides universal conversion of sensor signals and interactive communications for measurement, calibration, configuration and diagnostics. Mounting adapters, junction boxes and recharge kits are available.







1.5 Inch Union Mounting

1.5 Inch Ball Valve

Sanitary Mount

Hand	Rail	Mounting	Assembly
inunu	nun	mounting	, issembly

1 Inch Immersion Mounting with Junction Box (7 foot extension is standard)

	Specifications	
Measurement System Performance [†]	Range: 0 to 14 pH Resolution: 0.01 pH Accuracy: 0.1 % of reading Step Response Time: 90 % in 30 seconds	
Operational Environment	PEEK Sensor Head Temperature Range: -5 °C to 95 °C Maximum Pressure: 100 psig @ 95 °C Maximum Flow Rate: 10 ft/second	
	CPVC Sensor Head Temperature Range: -5 °C to 75 °C Maximum Pressure: 85 psig @ 75 °C Maximum Flow Rate: 10 ft/second	
Power Requirements‡	Voltage Range: 10 to 30 VDC Maximum Power: 200 mW Typical Power: 120 mW	
Construction	Process Electrode: "G", "HF", low temperature, pure water, or high temperature glass Ground Rod: Titanium, 316 stainless steel or Hastelloy [®] C O-rings: Viton [®] (other materials available) Sensor Head Material: PEEK or CPVC DataStick Material: 316 stainless steel, PEEK, or CPVC Weight: 1.2 lbs (PEEK or CPVC) ; 2.6 lbs (316 stainless steel)	
Units Of Measure	Measurement Units: pH, mV Temperature Units: °C, °F	
Calibration ⁺⁺	Automatic Buffer: 1 and 2 point Sample: 1 and 2 point Temperature: 1 point	
Temperature Compensation Options	Linear: % per °C Built-in tables: Ammonia or Morpholine	
Other Configuration Options	Sensor Filter: 0 to 100 seconds Temperature Filter: 0 to 100 seconds Auto Calibration Buffer Standards: (4, 7, 10) and DIN 19267	
Approvals And Ratings	Immunity & Emissions: CE certified 89/336/EEC: CISPER 11, EN61000 (-4-2, -4-3, -4-4, -4-6, 4-8) Safety: cULus listed; 367G E303570 Hazardous Locations: Haz Loc Class 1, Division 2, Groups A, B, C, D. Max ambient 50 °C	

 $^{\rm t}$ Note: Typical at 25 °C performance unaffected by cable length

* Note: Class II DC power supply required

⁺⁺Note: pH and temperature are pre-calibrated at the factory

^{‡‡}Note: Temperature can be entered manually

Thermo Scientific AquaSensors pH DataStick

- Global support—with experience that comes from supporting our customers for over 35 years throughout the world, our water quality specialists and customer support teams offer a quick, thorough and professional response to any problem encountered.
- Focus on user benefits—we work closely with you to define your needs, and ensure you are using the monitor in a way that improves your bottom line. For more information, contact your local water quality specialists or visit: www.thermoscientific.com/processwater.

pH DataStick Ordering Information				
Part No.	Description			
DS-b-t	DataStick			
Body Material (b)	1 = 316 stainless steel			
	2 = CPVC 3 = PEFK			
Mounting (t)	1 = 1 inch NPT front/back			
	2 = 1 inch NPT front only			
	3 = 1.5 inch ball valve			
	4 = 2 inch tri-clamp (sanitary)			
	5 = 2.5 inch tri-clamp (sanitary)			
PH-b-t-x-y-z-r	Differential pH Sensor Head			
Body Material (b)	2 = CPVC			
	3 = PEEK			
Electrode Type (t)	1 = Standard glass			
	2 = HF glass			
	3 = Low temperature			
	4 = Pure water			
	5 = High temperature			
Sensor Tip (x)	A = Protected			
	$\mathbf{B} = \text{Process flat}$			
	\mathbf{C} = Face seal (for flow chamber mounting)			
Filling Solution (y)	1 = Standard			
Salt Bridge (z)	A = Standard			
Ground Rod (r)	1 = 316 stainless steel			
	2 = Titanium			
	3 = Hastelloy C			



Thermo Fisher Scientific Water Analysis Instruments Chelmsford, MA USA Quality Management System Registered to ISO 9001

CA-b-nw-x-v **Communications Adapter** Body Material (b) 1 = 316 stainless steel 2 = CPVC 3 = PEEK 1A = RS232 ASCII Communications 2B = Modbus RTU (nw) 2A = Modbus RS232 4B = CANopen 7R = Ethernet 5R = DeviceNet 8R = USB 1 = 10 feet Cable Length (x) 2 = 20 feet 3 = 30 feet Cable **A** = Stripped wires

Termination (y)

	Accessories Ordering Information				
Part No.	Description				
Local Display Interface					
AV38	1/4 DIN, outputs, relays, digital				
	communications options				
Salt Bridge	Salt Bridge Replacements				
SBS01	PEEK protected				
SBS02	PEEK process flat				
SBS03	CPVC protected				
SBS04	CPVC process flat				
SBC01	Storage cap with sponge				
pH Solutions					
RCS03	pH storage solution, 60 mL bottle				
RCS01	Standard cell solution, 60 mL bottle				
910104	4 pH buffer, 500 mL bottle				
910107	7 pH buffer, 500 mL bottle				
910110	10 pH buffer, 500 mL bottle				
Mounting Hardware					
MH3022	1 inch tee mounting, CPVC				
MH3011	1 inch tee mounting, 316 SS				
MH1042	1.5 inch tee mounting, CPVC				
MH1041	1.5 inch tee mounting, 316 SS				
MH1112	1.5 inch ball valve, CPVC, low pressure				
MH1111	1.5 inch ball valve, 316 SS, low pressure				
MH1122	1.5 inch ball valve, CPVC, high pressure				
MH1121	1.5 inch ball valve, 316 SS, high pressure				
MH1242	Hand rail mounting assembly,				
	swivel/immersion, PVC				
MH3083	1 inch immersion mounting with junction box, PVC (7 foot extension is standard)				

Consult factory for other available sensor mounting options.

thermoscientific.com/processwater

© 2013 Thermo Fisher Scientific Inc. All rights reserved. Modbus is a registered trademark of Schneider Electric. DeviceNet is a trademark of ODVA. PROFIBUS is a trademark of PROFIBUS Nutzerorganisation e.V. Hastelloy is a registered trademark of Haynes International, Inc. Viton is a registered trademark of E. I. Du Pont De Nemours & Company. All other trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries.



Japan Tel: (81) 045-453-9175 wai.asia@thermofisher.com

Australia Tel: (613) 9757-4300 in Australia (1300) 735-295 InfoWaterAU@thermofisher.com



Water Analysis Instruments

Toll Free: 1-800-225-1480 Tel: 1-978-232-6000

info water@thermo.com

Netherlands Tel: (31) 033-2463887 info.water.uk@thermo.com

China Tel: (86) 21-68654588 wai.asia@thermofisher.com **India** Tel: (91) 22-4157-8800 wai.asia@thermofisher.com

> Singapore Tel: (65) 6778-6876 wai.asia@thermofisher.com